Silicone Strap Replacement Instructions FOR 1205ss METAL MESH GLOVES

REMOVING THE STRAP

Removing the strap is a straight forward process. Follow these helpful instructions for easy removal.

Step 1

Using a philips head screw driver, remove the set screw from the strap. Step 2

Holding the mesh cuff, gently start pulling the silicone strap out of the cuff.



8

Well Done. Now that the strap is removed, we can now move onto inserting the new strap.

INSERTING THE NEW STRAP Step 3

Now reverse the process, thread the new silicone strap through the metal mesh cuff.

Step 5 Straighten the strap out to insure that the strap

Step 4

Finish pulling the strap through the last loop of the metal mesh glove.





The finished metal mesh glove with a new silicone strap.

310 S. GRANT STREET | PO BOX 328 | MINERVA, OH 44657 FOR MORE INFORMATION PLEASE CONTACT: TOLL FREE: (800) 245-7117

is completely pulled through the loop. Using the philips screw driver, tighten the set screw.